

Location: 5376 FM 1784 Pleasanton, TX 78064 Phone: 210-663-4496

Mail: PO Box 39 Leming TX, 78050 Fax: 210-892-4496

Www. Terrabellaes.com

Email: sales@terrabellaes.com

## **LABPACKER**

## **Instructions for Set-up & Closure**

**Step 1)** Fold the top flaps in. Turn the container upside down, and fold the bottom flaps.

**Step 2)** Tape the bottom flaps with 3" filament pressure sensitive tape. The center strip of tape must extend a minimum of 4" over the edges, Tape the center seam, and use two additional strips of tape to seal the outer edges, forming an 'H' pattern.

**Step 3)** Insert the poly liner, and stretch around the containers interior walls until firmly in place.

**Step 4)** Fill the container with material.

**Step 5)** Once the box is full, twist the liner clockwise a minimum 3 times to secure the materials, and seal the bag. Secure with the appropriate twist tie 8" from the top of the liner.

**Step 6)** Carefully compress the filled liner of material into the container, and close the top flaps.

**Step 7)** Tape the top flaps with 3" filament pressure sensitive tape. The center strip of tape must extend a minimum of 4" over the edges, Tape the center seam, and use two additional strips of tape to seal the outer edges, forming an 'H' pattern.

**Packing Questions Contact** 

Terrabella Environmental Services at 210-663-4496